



DRY ICE FOGGER INSTRUCTIONS

www.ABCrental.com

READ CAREFULLY BEFORE DOING ANYTHING!

The top plate has two LED indicators - one red and one green.

RED: The red LED indicates that the water is at a good level and heater is on. The heater will NOT turn on unless there is enough water.

GREEN: The green LED indicates the water is at its optimal operating temperature and machine ready.

NOTE: During operation, the top plate becomes very hot. DO NOT TOUCH!

NOTE: There is an optional power input next to the main power input to heat the water faster. Connect this secondary input to a separate circuit to heat the water in half the time. **DO NOT PLUG BOTH POWER CORDS in the same circuit because the breaker will trip.**

1. Set the fogger on the dolly and move to where you want to place it. Keep away from children.
2. DO NOT USE AN EXTENSION CORD! Plug fogger into a grounded and protected circuit.
3. Raise the basket to its highest level with the operation lever on the side.
4. Open the lid (twist open the two lid latches) and fill with water until the red light comes on. The container can hold up to 4.5 gallon. Once filled, twist closed the two lid latches.
5. Using protective gear, load the basket with up to 10lbs of dry ice. The dry ice should be loaded at the last possible moment.
6. Close and latch the lid
7. Grab the operating lever and slowly lower the handle to the middle notch for LOW output or all the way down for HIGH output.
8. When output slows or stops, raise and refill the basket with dry ice safely.
9. You may need to refill the unit with water from time to time. Once refilled, wait for the red LED indicator to come on before repeating dry ice instructions.
10. NOTE: If the water level is too low, the unit will not turn on for safety reasons.
11. To return, drain the water, air dry and carefully return to ABC Rental.